



Line Drawing

(For use with the Crumble Card Buggy)




1

Pop the circle out from the base of the Card buggy.




2

Line up the plastic pen holder with the slot at the rear of the buggy.




3

Carefully slot the pen holder over the back of the buggy.



4

The lip at the front of the pen holder should align with the hole in the base.




5


Support the underside of the card whilst pressing the lip through the card at the front of the hole.



The pen holder should now sit firmly in place with the lip through the base.




If a pen / marker smaller than the pen holder is to be used then a small amount of rolled up paper or similar should be used to secure the pen into place..




Wiring the Line Drawing Robot.

No additional wiring is required from the standard Card Buggy.



Sample programs



Square




Pentagon



Equilateral Triangle

For more information on using your Crumble...
<http://redfernelectronics.co.uk/crumble-getting-started/>



Designed, manufactured and supplied by:

Mindsets (UK) Ltd
Shire Hill, Saffron Walden
CB11 3AQ



01992 716 052
www.mindsetsonline.co.uk
© 2017 Mindsets (UK) Ltd